

These instructions are for the **Millennium 4 (Black Remote)** used with the Amino box.

You should have a User's Guide that came with the remote. If your TV, VCR, or DVD player, Cable converter, or audio component does not respond to the black remote after trying all the codes listed for your brand, or if your brand is not listed at all, try searching for your code.

For example, to search for a code for your TV:

1. Turn on your TV.
2. On the black remote, press and hold SETUP until the LED blinks twice, then release SETUP.
3. Enter 9 – 9 – 1. The LED will blink twice.
4. Aim the remote control at the TV and slowly alternate between pressing POWER and TV. Stop when the TV turns off.
Note: In the search mode, the black remote will send codes from its library to the TV, starting with the most popular code first.
5. Press SETUP once to lock in the code.
6. To search for the codes of your other components, repeat steps 1 through 5, but substitute the appropriate key (i.e., VCR, CBL, or AUDIO) for the (VCR or DVD, Cable, or Audio) component you are searching for.

Helpful Hint: When powering up, push the STB button every time.

If you still are having problems with your remote, please contact ITC at 1-800-417-8667.