

These instructions are for the **Entone Remote** used with the Entone box.

Your remote control needs to be programmed to operate properly. It needs to be told how to run your television, which 'stream' it should change the channels for, and which Set Top Box (STB) (yours—not your neighbors) it is supposed to control.

1. Does the remote turn on/off the TV and control volume?

If YES, proceed to next question.

If NO, program remote using this procedure:

- a. Manually turn on the TV. (or auxiliary device)
- b. Press and release the TV key.
- c. Press and hold the Setup key until the key blinks twice and then release.
- d. The TV key will stay lit. Press the Power key once.
- e. Aim the remote at the TV and press and release Channel Up. The remote will auto scan at 10 second intervals. The TV key will be on, blinking every 10 seconds.
- f. If the TV turns off, a working code has been found. Press OK once to lock in the code. The TV key will blink twice.
- g. If all codes are exhausted, the TV key will blink fast 7 times and the search will be terminated.

2. Can you change channels or see the guide?

If YES, proceed to next question.

If NO, the remote needs to be programmed to control the correct stream.

- a. Be sure that the RF antenna is attached to the 'remote antenna' port on the back of the STB.
- b. ON THE STB, press and hold the 'OK' button for 10 seconds. When you release the button, the STB display will read 'RC REG'.
- c. ON THE REMOTE, press and hold the 'STB' button for 10 seconds. The 'STB' button will light up and stay lit. Release the 'STB' button.
- d. ON THE REMOTE, press and release the 'STB' button. Both the 'STB' and the 'AUX' buttons will illuminate.
- e. ON THE REMOTE, enter number for the stream:
 - 0 for infrared Stream 1 (Use "0" if the remote will always be used in the same room as the box. Also, use "0" if you are using the Entone Amulet single stream box.)
 - 1 for UHF Stream 1 (Channel 10)
 - 2 for UHF Stream 2 (Channel 23)
 - 3 for UHF Stream 3 (Channel 39)
- f. ON THE REMOTE, the 'STB' button will blink twice to indicate the registration was successful. ON THE STB, the display will read 'RC REG Dx' to indicate the registration was successful.

Helpful Hint: When powering up, push the STB button every time.

If you still are having problems with your remote, please contact ITC at 1-800-417-8667.